


Amana LGA50AW (BOM: PLGA50AW) 02 - CONTROL PANEL



Amana Residential Amana LGA50AW (BOM: PLGA50AW) Dryer Parts Parts Diagram 02 - CONTROL PANEL
 Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|-------------------------|---------------------------|---------------|---|
| 2 | 503674W | | | Cover, Top |
| 3 | Y503995 | | | Switch, Fabric Selector |
| 4 | 504102 | 40070501 | | Buzzer, Adjustable |
| 5 | 504180 | | Not Available | TIMER, 4 CYCLE |
| 6 | 504008W | | Not Available | CAP-END RH |
| 7 | Y00000000 | | Not Available | SEE NOTE SEE NOTE PANEL,HOME HOOD BACK |
| 8 | Y00000000 | | Not Available | SEE NOTE SEE NOTE Assy, Top Panel |
| 9 | 503901 | | Not Available | PANEL,SUPPORT CONTROL (MECH) |
| 10 | 503594W | | Not Available | PANEL, GRAPHIC |
| 11 | 502220W | | | Knob, Timer |
| 12 | 38424W | | | Switch, Rocker |
| 13 | 36701W | | | Knob |
| 14 | 504009W | 40012702W | | Endcap |