


# Amana LGA80AL (BOM: PLGA80AL) 02 - CONTROL PANEL



Amana [Residential Amana LGA80AL \(BOM: PLGA80AL\) Dryer Parts](#) Parts Diagram 02 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	501086	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
2	503674L		Not Available	COVER, TOP
3	<a href="#">62173</a>			Switch, Temperature Select
4	<a href="#">504166</a>			Switch, Signal
5	<a href="#">504175</a>			Moisture Sensor
6	<a href="#">501523</a>			Support, Circuit Board
7	<a href="#">503632</a>			Timer, 5 Cycle
8	34817L		Not Available	PANEL,END-RH
9	Y00000000		Not Available	SEE NOTE SEE NOTE PANEL,HOME HOOD BACK
10	Y00000000		Not Available	SEE NOTE SEE NOTE PANEL,DRYER TOP
11	504170		Not Available	SUPPORT, CONTROL PANEL
12	503596L		Not Available	PANEL, GRAPHIC
13	502220L	<a href="#">40013601C</a>		Assembly, Timer Knob
14	38424L	<a href="#">38424W</a>		Switch, Rocker

