


# Amana LGA80AW (BOM: PLGA80AW) 02 - CONTROL PANEL



Amana Residential Amana LGA80AW (BOM: PLGA80AW) Dryer Parts Parts Diagram 02 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	501086	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
2	<a href="#">503674W</a>			Cover, Top
3	<a href="#">62173</a>			Switch, Temperature Select
4	<a href="#">504166</a>			Switch, Signal
5	<a href="#">504175</a>			Moisture Sensor
6	<a href="#">501523</a>			Support, Circuit Board
7	<a href="#">503632</a>			Timer, 5 Cycle
8	34817W		Not Available	PANEL,END-RH
9	Y00000000		Not Available	SEE NOTE SEE NOTE PANEL,HOME HOOD BACK
10	Y00000000		Not Available	SEE NOTE SEE NOTE PANEL,DRYER TOP
11	504170		Not Available	SUPPORT, CONTROL PANEL
12	503596W		Not Available	PANEL, GRAPHIC
13	<a href="#">502220W</a>			Knob, Timer
14	<a href="#">38424W</a>			Switch, Rocker

