


# Amana LGD20AW (BOM: PLGD20AW) 02 - CONTROL PANEL



Amana Residential Amana LGD20AW (BOM: PLGD20AW) Dryer Parts Parts Diagram 02 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
2	<a href="#">503674W</a>			Cover, Top
3	<a href="#">Y503997</a>			Switch, Fabric Selector
5	<a href="#">Y504546</a>			Timer, 3 Cycle
6	504008W		Not Available	CAP-END RH
7	Y00000000		Not Available	SEE NOTE SEE NOTE PANEL,HOME HOOD BACK
8	Y00000000		Not Available	SEE NOTE SEE NOTE Assy, Top Panel
9	503901		Not Available	PANEL,SUPPORT CONTROL (MECH)
10	503592W		Not Available	PANEL, GRAPHIC
11	<a href="#">502220W</a>			Knob, Timer
13	<a href="#">36701W</a>			Knob
14	504009W	<a href="#">40012702W</a>		Endcap