



Amana Residential Amana LGD512 (BOM: P7762224W W) Dryer Parts Parts Diagram 07 - Page 1  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	R0603593		Not Available	CONTROL, HOOD ASSY
2	R0605715		Not Available	END CAP, L.H CHROME
3	R0605719	<a href="#">31248</a>		Cap, End-RH-Chrome
4	R0603592	<a href="#">61373</a>		Sub R0603592
5	R0600095		Not Available	SCREW
6	R0604013	<a href="#">502963</a>		Timer, 3 Cycle
7	R0600097	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
10	R0610066		Not Available	TIMER, KNOB ASSEMBLY
11	R0605714		Not Available	TRIM STRIP UPPER
14	R0600093	<a href="#">31260</a>		Screw, No.8 X 3/8 Ind H
15	R0605062		Not Available	CONTROL, SIGNAL
17	R0601035		Not Available	NUT
18	R0601546	<a href="#">32866</a>		Assembly, Knob-Rotary-Black
19	R0601501		Not Available	CLIP
20	R0602540		Not Available	SWITCH,FABRIC SELECTOR
23	R0603167		Not Available	REAR PANEL

24	R0600004	<a href="#">W10116760</a>	Screw
25	R0605702	Not Available	BRACKET, SWITCH, SIGNAL
26	R0602538	Not Available	BRACKET, SWITCH, FABRIC

