


# Amana LGD65AW (BOM: PLGD65AW) 03 - DOOR AND FRONT, ACCESS, AND TOP PANELS



Amana Residential Amana LGD65AW (BOM: PLGD65AW) Dryer Parts Parts Diagram 03 - DOOR AND FRONT, ACCESS, AND TOP PANELS  
 Click on the part number to view part

| Item | Original Part Number    | Replaced By               | Status        | Part Description                        |
|------|-------------------------|---------------------------|---------------|---|
| 1    | <a href="#">503688</a>  |                           |               | Screw, 10B-16 X .34 I                   |
| 2    | 501086                  | <a href="#">90767</a>     |               | Screw, 8A X 3/8 HeX Washer Head Tapping |
| 3    | 500343                  |                           | Not Available | PANEL,BACK(HOME HOOD)                   |
| 4    | 24903                   |                           | Not Available | STICKER,DISCONNECT POW                  |
| 5    | <a href="#">Y503876</a> |                           |               | Clip, Hold Down                         |
| 6    | 500085W                 | <a href="#">37001027</a>  |               | Panel, Top                              |
| 7    | 503661                  | <a href="#">27001200</a>  |               | Screw                                   |
| 8    | 500084                  | <a href="#">40130801</a>  |               | Bracket, Top Mount                      |
| 9    | 32671                   | <a href="#">Y014874</a>   |               | Screw, Idler Arm And Sleeve             |
| 10   | <a href="#">505187</a>  |                           |               | Locator, Panel                          |
| 11   | 56080                   | <a href="#">22001650</a>  |               | Fastener, Spring                        |
| 12   | Y504570                 | <a href="#">W10169313</a> |               | Switch-Dor                              |
| 13   | 504005                  | <a href="#">511056</a>    |               | Seal Front Panel                        |

|    |                         |                            |                          |
|----|-------------------------|----------------------------|--------------------------|
| 14 | 503639W                 | <a href="#">503656WP</a>   | Panel, Front             |
| 15 | 503661                  | <a href="#">27001200</a>   | Screw                    |
| 16 | 503648W                 | <a href="#">40045301WP</a> | Panel, Access            |
| 17 | 500281                  | Not Available              | STICKER                  |
| 18 | 54660                   | <a href="#">LA-1003</a>    | Door Catch Kit           |
| 19 | 503643W                 | <a href="#">37001028</a>   | Seal And Liner, Assembly |
| 20 | 500039                  | <a href="#">510181</a>     | Strike Doormetal         |
| 21 | 500223                  | <a href="#">40116201</a>   | Bracket, Door Strike     |
| 23 | 503646W                 | <a href="#">R9800012</a>   | Pull, Door               |
| 24 | 503642W                 | <a href="#">12002136</a>   | Door Handle              |
| 25 | <a href="#">Y503676</a> |                            | Hinge, Door And Top      |
| 26 | Y504105                 | <a href="#">Y504105A</a>   | Rack-Dry                 |
| 27 | <a href="#">503126</a>  |                            | Plug, Hinge Hole         |

*the laundry company*<sup>®</sup>

**Howes**  
*the laundry company*<sup>®</sup>

**Howes**  
*the laundry company*<sup>®</sup>