



Amana Residential Amana LW1201 (BOM: P7762110W W) Washer Parts Parts Diagram 05 - Page 1
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	R0603161		Not Available	HOOD AND MOUNTING PLATE
2	R0605698		Not Available	END CAP, LEFT, BLACK
"	R0605696		Not Available	END CAP, RIGHT, BLACK
3	R0603581		Not Available	PANEL, GRAPHICS
4	R0603585		Not Available	KNOB, BLACK
5	R0603586	32995		Assembly, Timer Skirt an Ring-
6	R0600095		Not Available	SCREW
7	R0604010	31238		Timer, 2 Cycle
8	R0600093	31260		Screw, No.8 X 3/8 Ind H
9	R0602525	31266		Switch, Pressure-Rotary
10	R0602522		Not Available	TEMPERATURE SWITCH
11	R0601022		Not Available	NUT
12	R0600004	W10116760		Screw
13	R0601546	32866		Assembly, Knob-Rotary-Black
14	R0601501		Not Available	CLIP

