



Amana Residential Amana LW2201L (BOM: P1164303W L) Washer Parts Diagram 05 - Page 14  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	34288	<a href="#">40065102</a>		Screw, Shoulder 1/4
2	34289	<a href="#">36472</a>		O-Ring
3	34504	<a href="#">R9900189</a>		Kit, Drive Bell And Seal
4	34184	<a href="#">R9900189</a>		Kit, Drive Bell And Seal
5	Y29220	<a href="#">40016301</a>		Nut, Lock
6	29728	<a href="#">40008301</a>		Insert, Spline
7	495P3	<a href="#">R9900552</a>		Hub And Seal
8	33514	<a href="#">40000501W</a>		Agitator, Flex Vane
9	27125	<a href="#">39122</a>		Gasket, Washtub
10	33227	<a href="#">33227P</a>		Assembly- Tran
11	27200		Not Available	CAP SCREW
12	<a href="#">02431</a>			Lockwasher, 1/4 Ext Shk
13	27143		Not Available	BALANCE RING
14	27182	<a href="#">40004201P</a>		Main Bearing Assembly
15	01355		Not Available	SCREW
16	02834		Not Available	LOCKWASHER,5/16 EXT SH

17	<a href="#">27222</a>		Nut, Retainer 5/16-18
18	<a href="#">27187</a>		Flinger
19	27166	Not Available	WASHER,BEARING HOUSING
20	32989	<a href="#">35035</a>	Guard, Clothes
21	29074	<a href="#">39252P</a>	Wash Tub
22	<a href="#">28094</a>		Gasket
23	27202	<a href="#">W1011678Z</a>	Screw

