



Amana Residential Amana LW2302 (BOM: P7762112W W) Washer Parts Diagram 06 - Page 13
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	R0600092		Not Available	SCREW
2	R0600554		Not Available	``O`` RING WASHER
3	R0603552	R9900189		Kit, Drive Bell And Seal
4	R0603553	R9900189		Kit, Drive Bell And Seal
5	R0601034	40016301		Nut, Lock
6	R0605674	40008301		Insert, Spline
7	R0605675	R9900552		Hub And Seal
8	R0603551	40000501W		Agitator, Flex Vane
12	R0604505	39122		Gasket, Washtub
13	R0607505	33227P		Assembly- Tran
14	R0600022		Not Available	SCREW
15	R0600520	02431		Lockwasher, 1/4 Ext Shk
16	R0610012		Not Available	ASSY,BALANCE RING-COMPL
17	R0610011	40004201P		Main Bearing Assembly
18	R0600021		Not Available	SCREW
19	R0600519		Not Available	LOCKWASHER

20	R0601013	27222	Nut, Retainer 5/16-18
21	R0605536	27187	Flinger
22	R0600518	Not Available	WASHER
23	R0603569	33521	Filter Lint/Clothes Guard
25	R0603141	Not Available	WASH TUB
26	R0604504	28094	Gasket
27	R0600019	3400527	Screw
28	R0603509	R9900189	Kit, Drive Bell And Seal

