



30

Amana Residential Amana LW2303 (BOM: P7762119W W) Washer Parts Diagram 06 - Page 13  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	R0600092		Not Available	SCREW
2	R0600554		Not Available	``O`` RING WASHER
3	R0603552	<a href="#">R9900189</a>		Kit, Drive Bell And Seal
4	R0603553	<a href="#">R9900189</a>		Kit, Drive Bell And Seal
5	R0601034	<a href="#">40016301</a>		Nut, Lock
6	R0605674	<a href="#">40008301</a>		Insert, Spline
7	R0605675	<a href="#">R9900552</a>		Hub And Seal
8	R0603551	<a href="#">40000501W</a>		Agitator, Flex Vane
12	R0604505	<a href="#">39122</a>		Gasket, Washtub
13	R0607505	<a href="#">33227P</a>		Assembly- Tran
14	R0600022		Not Available	SCREW
15	R0600520	<a href="#">02431</a>		Lockwasher, 1/4 Ext Shk
16	R0610012		Not Available	ASSY,BALANCE RING-COMPL
17	R0610011	<a href="#">40004201P</a>		Main Bearing Assembly
18	R0600021		Not Available	SCREW
19	R0600519		Not Available	LOCKWASHER

20	R0601013	<a href="#">27222</a>	Nut, Retainer 5/16-18
21	R0605536	<a href="#">27187</a>	Flinger
22	R0600518	Not Available	WASHER
23	R0603569	<a href="#">33521</a>	Filter Lint/Clothes Guard
25	R0603141	Not Available	WASH TUB
26	R0604504	<a href="#">28094</a>	Gasket
27	R0600019	<a href="#">3400527</a>	Screw
28	R0603509	<a href="#">R9900189</a>	Kit, Drive Bell And Seal

