



Amana Residential Amana LW2402 (BOM: P7762113W W) Washer Parts Diagram 07 - Page 2
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	R0603162		Not Available	HOOD AND MOUNTING PLATE
2	R0605698		Not Available	END CAP, LEFT, BLACK
"	R0605696		Not Available	END CAP, RIGHT, BLACK
3	R0603584		Not Available	PANEL, GRAPHICS
4	R0603585		Not Available	KNOB, BLACK
5	R0603588		Not Available	SKIRT-TIMER KNOB
6	R0600095		Not Available	SCREW
7	R0604016	32039		Timer, 4 Cycle
8	R0600093	31260		Screw, No.8 X 3/8 Ind H
9	R0602525	31266		Switch, Pressure-Rotary
11	R0601022		Not Available	NUT
12	R0600004	W10116760		Screw
13	R0601546	32866		Assembly, Knob-Rotary-Black
14	R0601501		Not Available	CLIP
15	R0603103		Not Available	PANEL, REAR
16	R0600004	W10116760		Screw

