


Amana LW2402 (BOM: P7762113W W) 10 - SWITCH AND BRACKET ASSY



16

Amana Residential Amana LW2402 (BOM: P7762113W W) Washer Parts Parts Diagram 10 - SWITCH AND BRACKET ASSY

[Click on the part number to view part](#)

| Item | Original Part Number | Replaced By            | Status        | Part Description         |
|------|----------------------|------------------------|---------------|--------------------------|
| 1    | R0602507             | <a href="#">27612</a>  |               | Switch, Lid              |
| 2    | R0600011             |                        | Not Available | SCREW                    |
| 3    | R0605504             | <a href="#">27602</a>  |               | Lever, Out-Of-Bal Switch |
| 4    | R0605506             |                        | Not Available | SPRING                   |
| 5    | R0605505             |                        | Not Available | BRACKET                  |
| 6    | R0601503             |                        | Not Available | U-CLIP                   |
| 7    | R0601504             | <a href="#">27610</a>  |               | Clip, U                  |
| 8    | R0601006             |                        | Not Available | NUT                      |
| 9    | R0600012             | <a href="#">489464</a> |               | Screw                    |
| 10   | R0605671             |                        | Not Available | SWITCH SHIELD            |
| 11   | R0601032             | <a href="#">29043</a>  |               | Nut, Push                |