



Amana Residential Amana LW2403 (BOM: P7762120W W) Washer Parts Diagram 07 - Page 2  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	R0603162		Not Available	HOOD AND MOUNTING PLATE
2	R0605698		Not Available	END CAP, LEFT, BLACK
"	R0605696		Not Available	END CAP, RIGHT, BLACK
3	R0603584		Not Available	PANEL, GRAPHICS
4	R0603585		Not Available	KNOB, BLACK
5	R0603588		Not Available	SKIRT-TIMER KNOB
6	R0600095		Not Available	SCREW
7	R0604016	<a href="#">32039</a>		Timer, 4 Cycle
8	R0600093	<a href="#">31260</a>		Screw, No.8 X 3/8 Ind H
9	R0602525	<a href="#">31266</a>		Switch, Pressure-Rotary
11	R0601022		Not Available	NUT
12	R0600004	<a href="#">W10116760</a>		Screw
13	R0601546	<a href="#">32866</a>		Assembly, Knob-Rotary-Black
14	R0601501		Not Available	CLIP
15	R0603103		Not Available	PANEL, REAR
16	R0600004	<a href="#">W10116760</a>		Screw

