



32

Amana Residential Amana LW2403 (BOM: P7762127W W) Washer Parts Diagram 04 - Page 14
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	R0600092		Not Available	SCREW
2	R0600554		Not Available	“O” RING WASHER
3	R0603552	R9900189		Kit, Drive Bell And Seal
4	R0603553	R9900189		Kit, Drive Bell And Seal
5	R0601034	40016301		Nut, Lock
6	R0605674	40008301		Insert, Spline
7	R0605675	R9900552		Hub And Seal
8	R0603551	40000501W		Agitator, Flex Vane
9	R0603549	33510		Assembly, Dispenser-Fabric
10	R0603515		Not Available	SALES ITEM ONLY (DISPENSER)
11	R0603550		Not Available	SALES ITEM
12	R0604505	39122		Gasket, Washtub
13	R0607505	33227P		Assembly- Tran
14	R0600022		Not Available	SCREW
15	R0600520	02431		Lockwasher, 1/4 Ext Shk
				ASSY BALANCE RING

16	R0610012		Not Available	ASST,BALANCE RING- COMPL
17	R0610011	40004201P		Main Bearing Assembly
18	R0600021		Not Available	SCREW
19	R0600519		Not Available	LOCKWASHER
20	R0601013	27222		Nut, Retainer 5/16-18
21	R0605536	27187		Flinger
22	R0600518		Not Available	WASHER
23	R0603569	33521		Filter Lint/Clothes Guard
25	R0603165	39248P		Wash Tub
26	R0604504	28094		Gasket
27	R0600019	3400527		Screw
28	R0603509	R9900189		Kit, Drive Bell And Seal

the laundry company[®]

the laundry company[®]

the laundry company[®]