



Amana Residential Amana LW2501L (BOM: P1164306W L) Washer Parts Parts Diagram 10 - PUMP ASSY  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">33122</a>			Hood And Mounting Plate
2	31249		Not Available	CAP,END-L.H.-CHROME
"	<a href="#">31248</a>			Cap, End-RH-Chrome
3	<a href="#">32893</a>			Panel, Graphic-Amana
4	31239	<a href="#">31239P</a>		Timer 3 Cycle Package
5	33127		Not Available	ASSY,TIMER SKIRT & RIN
6	33126		Not Available	KNOB, TIMER
7	<a href="#">31260</a>			Screw, No.8 X 3/8 Ind H
9	21300		Not Available	SWITCH,TEMPERATURE
11	23962	<a href="#">W10116760</a>		Screw
12	33117		Not Available	ASSY,KNOB-ROTARY-GRAY
13	10519		Not Available	RETAINER
14	33619		Not Available	CONTROL HOOD REAR PANEL
15	23962	<a href="#">W10116760</a>		Screw
16	31752		Not Available	SCREW,No.8ABX3/4 POZIDRI

