


**Amana LW2501W2 (BOM: PLW2501W2 B) 13 - GRAPHIC PANEL, CTRL  
MTG PLATE AND CTRLS**



Amana Residential Amana LW2501W2 (BOM: PLW2501W2 B) Washer Parts Parts Diagram 13 - GRAPHIC PANEL, CTRL MTG PLATE AND CTRLS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	34823		Not Available	COVER, TOP
2	23962	<a href="#">W10116760</a>		Screw
3	Y34826		Not Available	DIFFUSER,LAMP-CLEAR
4	34904	<a href="#">489355</a>		Screw, 8 X 1/2
6	501086	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
7	34815		Not Available	PANEL, END R.H. (BLK)
8	34903		Not Available	PANEL, BACK HOOD (USE 37782)
9	34902P		Not Available	TOP
10	34821		Not Available	CONTROL MOUNTING PLATE
12	33817		Not Available	ASSY,TIMER SKIRT-BLACK
13	<a href="#">33897</a>			Knob, Timer-Washer-Blac
14	<a href="#">34816</a>			Panel, End