



Amana Residential Amana LW2502G (BOM: P1118408W G) Washer Parts Diagram 06 - Page 13

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	R0600092		Not Available	SCREW
2	R0600554		Not Available	``O`` RING WASHER
3	R0603552	R9900189		Kit, Drive Bell And Seal
4	R0603553	R9900189		Kit, Drive Bell And Seal
5	R0601034	40016301		Nut, Lock
6	R0605674	40008301		Insert, Spline
7	R0605723	R9900552		Hub And Seal
8	R0603624	40000501W		Agitator, Flex Vane
"	R0603551	40000501W		Agitator, Flex Vane
9	R0604505	39122		Gasket, Washtub
10	R0607505	33227P		Assembly- Tran
11	R0600022		Not Available	SCREW
12	R0600520	02431		Lockwasher, 1/4 Ext Shk
13	R0610012		Not Available	ASSY,BALANCE RING-COMPL
14	R0610011	40004201P		Main Bearing Assembly
15	R0600021		Not Available	SCREW

16	R0600519	Not Available	LOCKWASHER
17	R0601013	27222	Nut, Retainer 5/16-18
18	R0605536	27187	Flinger
19	R0600518	Not Available	WASHER
20	R0603611	35035	Guard, Clothes
21	R0603214	39248P	Wash Tub
22	R0604504	28094	Gasket
23	R0600019	3400527	Screw
24	R0603509	R9900189	Kit, Drive Bell And Seal
25	R0610072	39371	Filter Lin
26	R0603625	40002101W	Assembly, Fabric Softner

Howes
the laundry company[®]

Howes
the laundry company[®]

Howes
the laundry company[®]