



Amana Residential Amana LW2503G (BOM: P1118411W G) Washer Parts Parts Diagram 05 - Page 1
 Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|----------------------|---------------------------|---------------|-----------------------------|
| 1 | R0603161 | | Not Available | HOOD AND MOUNTING PLATE |
| 2 | R0605698 | | Not Available | END CAP, LEFT, BLACK |
| " | R0605696 | | Not Available | END CAP, RIGHT, BLACK |
| 3 | R0603621 | | Not Available | GRAPHICS PANEL |
| 4 | R0603585 | | Not Available | KNOB, BLACK |
| 5 | R0603587 | | Not Available | ASSY,TIMER SKIRT&RING- |
| 6 | R0600095 | | Not Available | SCREW |
| 7 | R0604011 | 31239P | | Timer 3 Cycle Package |
| 8 | R0600093 | 31260 | | Screw, No.8 X 3/8 Ind H |
| 9 | R0602525 | 31266 | | Switch, Pressure-Rotary |
| 10 | R0602522 | | Not Available | TEMPERATURE SWITCH |
| 11 | R0601022 | | Not Available | NUT |
| 12 | R0600004 | W10116760 | | Screw |
| 13 | R0601546 | 32866 | | Assembly, Knob-Rotary-Black |
| 14 | R0601501 | | Not Available | CLIP |
| 15 | R0603231 | | Not Available | PANE, REAR |

