


Amana LW2503W (BOM: P1164310W W) 10 - PUMP ASSY



Amana Residential Amana LW2503W (BOM: P1164310W W) Washer Parts Parts Diagram 10 - PUMP ASSY
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	33102		Not Available	ASSY,HOOD & MTG PLATE-
2	32864		Not Available	CAP,END-R.H.-BLK W/SLV
"	32863		Not Available	CAP,END-L.H.-BLK W/SLV
3	33967	WB2X6195		Hinge Pin
4	31238			Timer, 2 Cycle
5	32995			Assembly, Timer Skirt an Ring-
6	32622		Not Available	TIMER KNOB
7	31260			Screw, No.8 X 3/8 Ind H
8	31266			Switch, Pressure-Rotary
9	28118		Not Available	SWITCH,WATER TEMPERATU
"	21300		Not Available	SWITCH,TEMPERATURE
10	57584		Not Available	NUT
11	23962	W10116760		Screw
12	32866			Assembly, Knob-Rotary-Black
13	10519		Not Available	RETAINER

14	33619	Not Available	CONTROL HOOD REAR PANEL
15	23962	W10116760	Screw
16	31752	Not Available	SCREW, No.8ABX3/4 POZIDRI
18	32874	Not Available	TRIM,BOTTOM-AMANA

