



Amana Residential Amana LW3302W (BOM: P1164313W W) Washer Parts Parts Diagram 07 - Page 2
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	33102		Not Available	ASSY,HOOD & MTG PLATE-
2	32864		Not Available	CAP,END-R.H.-BLK W/SLV
"	32863		Not Available	CAP,END-L.H.-BLK W/SLV
3	33964		Not Available	PANEL,GRAPHIC-AMANA
5	32622		Not Available	TIMER KNOB
"	32996		Not Available	ASSY,TIMER SKIRT&RING-
6	31752		Not Available	SCREW,No.8ABX3/4 POZIDRI
7	32039			Timer, 4 Cycle
8	31260			Screw, No.8 X 3/8 Ind H
9	31266			Switch, Pressure-Rotary
10	28118		Not Available	SWITCH,WATER TEMPERATU
11	Q6163		Not Available	NUT
12	23962	W10116760		Screw
13	32866			Assembly, Knob-Rotary-Black
14	10519		Not Available	RETAINER

