



Amana Residential Amana LW3403G (BOM: P1118420W G) Washer Parts Parts Diagram 07 - Page 2  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	R0603231		Not Available	PANE, REAR
2	R0605696		Not Available	END CAP, RIGHT, BLACK
"	R0605698		Not Available	END CAP, LEFT, BLACK
3	R0603618		Not Available	GRAPHICS PANEL
4	R0603585		Not Available	KNOB, BLACK
5	R0603588		Not Available	SKIRT-TIMER KNOB
6	R0604017		Not Available	TIMER
7	R0604017		Not Available	TIMER
8	R0600093	<a href="#">31260</a>		Screw, No.8 X 3/8 Ind H
9	R0602525	<a href="#">31266</a>		Switch, Pressure-Rotary
10	R0602536		Not Available	ROTARY TEMPERATURE SWITCH
11	R0601022		Not Available	NUT
12	R0600004	<a href="#">W10116760</a>		Screw
13	R0601546	<a href="#">32866</a>		Assembly, Knob-Rotary-Black
14	R0601501		Not Available	CLIP
15	R0603103		Not Available	PANEL, REAR

