


Amana LW3502L2 (BOM: PLW3502L2 A) 09 - GRAPHIC PANEL, CTRL  
MTG PLATE AND CTRLS



Amana Residential Amana LW3502L2 (BOM: PLW3502L2 A) Washer Parts Parts Diagram 09 - GRAPHIC PANEL, CTRL  
MTG PLATE AND CTRLS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y34826		Not Available	DIFFUSER,LAMP-CLEAR
2	34823		Not Available	COVER, TOP
3	23962	<a href="#">W10116760</a>		Screw
4	34904	<a href="#">489355</a>		Screw, 8 X 1/2
5	31239	<a href="#">31239P</a>		Timer 3 Cycle Package
6	501086	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
7	34815		Not Available	PANEL, END R.H. (BLK)
8	34903		Not Available	PANEL, BACK HOOD (USE 37782)
9	34902P		Not Available	TOP
10	34821		Not Available	CONTROL MOUNTING PLATE
11	Y36614		Not Available	PANEL, GRAPHICS
12	<a href="#">34848</a>			Assembly, Timer Skirt
13	34844		Not Available	KNOB,TIMER

14 [34847](#)  
15 [34816](#)  
16 [35115](#)  
17 36045

[40055101](#)

Assembly, Knob-Rotary  
Panel, End  
Switch, TemPerature 3 P  
Switch, Pressure

