


**Amana LW4303L (BOM: P1163304W L) 07 - FRONT PANEL, BASE & CABINET ASSY**



**FRONT PANEL, BASE AND CABINET ASSEMBLY**

Amana Residential Amana LW4303L (BOM: P1163304W L) Washer Parts Parts Diagram 07 - FRONT PANEL, BASE & CABINET ASSY

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">35865</a>			Clip, Hold-Down Front Panel
2	Y35097		Not Available	BRACE, FRT PNL
3	27196	<a href="#">27001200</a>		Screw
4	<a href="#">Y56128</a>			Pad, Bumper
5	56079	<a href="#">505187</a>		Locator, Panel
6	32671	<a href="#">Y014874</a>		Screw, Idler Arm And Sleeve
7	<a href="#">36226</a>			Pad, Bumper .25
8	34499		Not Available	SCREW, No.10B X 1/4 TAP IN HX
9	56392		Not Available	SCREW,8-18 X 3/8 TAPPI
10	Y00000000		Not Available	SEE NOTE SEE NOTE GROUND WIRE, GREEN
11	<a href="#">Y27103</a>			Hinge, Hold-Down Lug
12	34475WP	<a href="#">38612WP</a>		Kit-Service
"	34475LP	<a href="#">38612LP</a>		Kit Service Cabinet

"	34475HP		Not Available	KIT,SERVICE CABINET
13	<a href="#">34443</a>			Assembly, Leg And Stabilier
14	35148		Not Available	SCREW,1/4-14 X 3/8 HX HD
15	36036		Not Available	BRACKET,SLL-RIGHT
16	<a href="#">34434P</a>			Assembly Nut/Leg Base
17	Y34319	<a href="#">22003428</a>		Leg, Adjustable
18	34318	<a href="#">40016001</a>		Foot, Rubber
19	Y21899	<a href="#">40038101</a>		Nut, Leg
20	36108		Not Available	SNUBBER PAD & ISOLATOR
21	<a href="#">36037</a>			Bracket, Sll-Left
22	<a href="#">28102</a>			Locator, Panel
23	<a href="#">34656WP</a>			Assembly, Front Panel
"	34656HP		Not Available	ASSY,FRONT PANEL
"	<a href="#">34656LP</a>			Assembly, Front Panel

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>