


# Amana LW4303W (BOM: P1163303W W) 02 - AGITATOR & DRIVE BELL



## AGITATOR AND DRIVE BELL

Amana [Residential Amana LW4303W \(BOM: P1163303W W\) Washer Parts](#) Parts Diagram 02 - AGITATOR & DRIVE BELL

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	34155	<a href="#">40002101W</a>		Assembly, Fabric Softner
2	33174	<a href="#">40000501W</a>		Agitator, Flex Vane
3	34288	<a href="#">40065102</a>		Screw, Shoulder 1/4
4	<a href="#">36472</a>			O-Ring
5	34504P	<a href="#">R9900189</a>		Kit, Drive Bell And Seal
6	Y00000000		Not Available	SEE NOTE WASHTUB