


**Amana LW6111WB (BOM: PLW6111WB A) 08 - GRAPHIC PANEL, CTRL
MTG PLATE & CTRLS**



GRAPHIC PANEL, CONTROL MOUNTING PLATE AND CONTROLS
 (Models CW4202W2, LW2501L2, LW2501W2, LW3502L2, LW3502W2, LW3503L2,
 LW3503W2, LW4203L2, LW4203W2, LW6111LB AND LW6111WB)

Amana [Residential Amana LW6111WB \(BOM: PLW6111WB A\) Washer Parts](#) Parts Diagram 08 - GRAPHIC PANEL,
 CTRL MTG PLATE & CTRLS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	501086	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
2	34816			Panel, End
3	35115			Switch, Temperature 3 P
4	36045	40055101		Switch, Pressure
"	35010	39035		Switch, Pressure-Var
5	Y34826		Not Available	DIFFUSER,LAMP-CLEAR
6	34823		Not Available	COVER, TOP
7	23962	W10116760		Screw
8	34904	489355		Screw, 8 X 1/2
9	31239	31239P		Timer 3 Cycle Package
10	34815		Not Available	PANEL, END R.H. (BLK)
11	Y00000000		Not Available	SEE NOTE CONTROL HOOD REAR PANEL -- (SEE CABINET TOP AND CONTROL HOOD REAR PANEL PAGE)

12	Y00000000	Not Available	SEE NOTE CABINET TOP -- (SEE CABINET TOP AND CONTROL HOOD REAR PANELPAGE)
13	34821	Not Available	CONTROL MOUNTING PLATE
14	Y36614	Not Available	PANEL, GRAPHICS
"	36883	Not Available	PANEL, GRAPHICS
"	36865	Not Available	PANEL, GRAPHICS
"	36884	Not Available	PANEL, GRAPHICS
15	34848		Assembly, Timer Skirt
16	34844	Not Available	KNOB, TIMER
17	34847		Assembly, Knob-Rotary

Howes
the laundry company®

Howes
the laundry company®

Howes
the laundry company®