


Amana LW6123WM (BOM: PLW6123WM A) 15 - GRAPHIC PANEL, CTRL  
MTG PLATE AND CTRLS



Amana Residential Amana LW6123WM (BOM: PLW6123WM A) Washer Parts Parts Diagram 15 - GRAPHIC PANEL,  
CTRL MTG PLATE AND CTRLS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y34826		Not Available	DIFFUSER,LAMP-CLEAR
2	34823		Not Available	COVER, TOP
3	23962	<a href="#">W10116760</a>		Screw
4	34904	<a href="#">489355</a>		Screw, 8 X 1/2
5	<a href="#">36607</a>			Timer, 4 Cycle
6	501086	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
7	34815		Not Available	PANEL, END R.H. (BLK)
8	34903		Not Available	PANEL, BACK HOOD (USE 37782)
9	34902P		Not Available	TOP
10	34821		Not Available	CONTROL MOUNTING PLATE
11	36804		Not Available	PANEL, GRAPHICS
12	<a href="#">34848</a>			Assembly, Timer Skirt
13	34844		Not Available	KNOB,TIMER

14	<a href="#">34847</a>		Assembly, Knob-Rotary
15	<a href="#">34816</a>		Panel, End
16	36335	<a href="#">40046601</a>	Switch, Temperature Select
17	36045	<a href="#">40055101</a>	Switch, Pressure
18	35118	<a href="#">40039501</a>	Switch, Speed

