


Amana LW6153WB (BOM: PLW6153WB A) 10 - GRAPHIC PANEL, CTRL MTG PLATE AND CTRLS



Amana Residential Amana LW6153WB (BOM: PLW6153WB A) Washer Parts Parts Diagram 10 - GRAPHIC PANEL, CTRL MTG PLATE AND CTRLS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y34826		Not Available	DIFFUSER,LAMP-CLEAR
2	34824		Not Available	TOP COVER
3	23962	W10116760		Screw
4	34904	489355		Screw, 8 X 1/2
5	31239	31239P		Timer 3 Cycle Package
"	31241			Timer, 240V/50Hz-3 Cycle
6	501086	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
7	34817		Not Available	END CAP(RIGHT)
8	34903		Not Available	PANEL, BACK HOOD (USE 37782)
9	34902P		Not Available	TOP
10	34821		Not Available	CONTROL MOUNTING PLATE
11	37681W		Not Available	PANEL, GRAPHICS (WHITE)
"	36613		Not Available	GRAPHIC PANEL

12	36700	Not Available	TIMER KNOB SKIRT
13	35333	Not Available	TIMER KNOB
14	36701	Not Available	KNOB, TEMP
15	34818	Not Available	END CAP(LEFT)
16	35115		Switch, TemPerature 3 P
17	35010	39035	Switch, Pressure-Var

