


**Amana LW6163LM (BOM: PLW6163LM A) 08 - GRAPHIC PANEL, CTRL  
MTG PLATE & CTRLS**



**GRAPHIC PANEL, CONTROL MOUNTING PLATE AND CONTROLS  
(LW6163LM, LW6163WM, LW8413L2, LW8413W2 AND LW8463W2)**

Amana [Residential Amana LW6163LM \(BOM: PLW6163LM A\) Washer Parts](#) Parts Diagram 08 - GRAPHIC PANEL, CTRL MTG PLATE & CTRLS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	501086	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
2	34818L		Not Available	PANEL,END-LH
"	34818W		Not Available	PANEL,END-LH
3	36335	<a href="#">40046601</a>		Switch, Temperature Select
4	36045	<a href="#">40055101</a>		Switch, Pressure
5	35038		Not Available	SWITCH/ WHITE
6	<a href="#">34829</a>			Diffuser, Lamp-Clear
7	<a href="#">34824L</a>			Cover, Top
"	34824W		Not Available	COVER, TOP (COMPUTOR)
8	23962	<a href="#">W10116760</a>		Screw
9	34841		Not Available	STARTER,FLUORESCENT
"	34837		Not Available	BULB,FLUORESCENT
"	<a href="#">34836</a>			Assembly, Fluorescent Light
10	<a href="#">36773</a>			Timer, 5 Cycle

11	35118	<a href="#">40039501</a>	Switch, Speed
12	34904	<a href="#">489355</a>	Screw, 8 X 1/2
13	34817W		Not Available
	34817L		Not Available
14	Y00000000		Not Available
15	Y00000000		Not Available
16	34821		Not Available
17	36624W		Not Available
"	36611W		Not Available
"	36611L		Not Available
"	36616W		Not Available
"	36616L		Not Available
"	36624L		Not Available
18	<a href="#">36700W</a>		Knob Skirt
"	<a href="#">36700L</a>		Skirt, Timer
19	<a href="#">35333L</a>		Knob, Timer
"	<a href="#">35333W</a>		Knob, Timer
20	<a href="#">36701W</a>		Knob
"	<a href="#">36701L</a>		Knob

