

Amana LW6163WM (BOM: PLW6163WM) 16 - GRAPHIC PANEL, CTRL
MTG PLATE AND CTRLS



Amana [Residential Amana LW6163WM \(BOM: PLW6163WM\) Washer Parts](#) Parts Diagram 16 - GRAPHIC PANEL,
CTRL MTG PLATE AND CTRLS
[Click on the part number to view part](#)

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|-----------------------|---------------------------|---------------|---|
| 1 | 34829 | | | Diffuser, Lamp-Clear |
| 2 | 34824 | | Not Available | TOP COVER |
| 3 | 23962 | W10116760 | | Screw |
| 4 | 501086 | 90767 | | Screw, 8A X 3/8 HeX Washer Head Tapping |
| 5 | 34836 | | | Assembly, Fluorescent Light |
| 6 | 35118 | 40039501 | | Switch, Speed |
| 7 | 36773 | | | Timer, 5 Cycle |
| 8 | 34904 | 489355 | | Screw, 8 X 1/2 |
| 9 | 34817 | | Not Available | END CAP(RIGHT) |
| 10 | 34903 | | Not Available | PANEL, BACK HOOD (USE 37782) |
| 11 | 34902P | | Not Available | TOP |
| 12 | 34821 | | Not Available | CONTROL MOUNTING PLATE |
| 14 | 36700 | | Not Available | TIMER KNOB SKIRT |

| | | | |
|----|-------|--------------------------|----------------------------|
| 15 | 35333 | Not Available | TIMER KNOB |
| 16 | 36701 | Not Available | KNOB, TEMP |
| 17 | 34818 | Not Available | END CAP(LEFT) |
| 18 | 36335 | 40046601 | Switch, Temperature Select |
| 19 | 36045 | 40055101 | Switch, Pressure |
| 20 | 35038 | Not Available | SWITCH/ WHITE |

