


Amana LW8312L2 (BOM: PLW8312L2 A) 11 - GRAPHIC PANEL, CTRL MTG PLATE AND CTRLS



Amana Residential Amana LW8312L2 (BOM: PLW8312L2 A) Washer Parts Parts Diagram 11 - GRAPHIC PANEL, CTRL MTG PLATE AND CTRLS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
2	34824		Not Available	TOP COVER
3	23962	W10116760		Screw
4	34904	489355		Screw, 8 X 1/2
5	36773			Timer, 5 Cycle
6	501086	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
7	34817		Not Available	END CAP(RIGHT)
8	34903		Not Available	PANEL, BACK HOOD (USE 37782)
9	34902P		Not Available	TOP
10	34821		Not Available	CONTROL MOUNTING PLATE
11	36611		Not Available	PANEL, GRAPHICS
12	36700		Not Available	TIMER KNOB SKIRT
13	35333		Not Available	TIMER KNOB
14	36701		Not Available	KNOB, TEMP

15	34818	Not Available	END CAP(LEFT)
16	36335	40046601	Switch, Temperature Select
17	35118	40039501	Switch, Speed
18	36045	40055101	Switch, Pressure

