


**Amana LW8312L2 (BOM: PLW8312L2 A) 16 - GRAPHIC PANEL, CTRL
MTG PLATE AND CTRLS**



Amana Residential Amana LW8312L2 (BOM: PLW8312L2 A) Washer Parts Parts Diagram 16 - GRAPHIC PANEL, CTRL
MTG PLATE AND CTRLS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	34829			Diffuser, Lamp-Clear
2	34824		Not Available	TOP COVER
3	23962	W10116760		Screw
4	501086	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
5	34836			Assembly, Fluorescent Light
6	35118	40039501		Switch, Speed
7	36773			Timer, 5 Cycle
8	34904	489355		Screw, 8 X 1/2
9	34817		Not Available	END CAP(RIGHT)
10	34903		Not Available	PANEL, BACK HOOD (USE 37782)
11	34902P		Not Available	TOP
12	34821		Not Available	CONTROL MOUNTING PLATE
13	36611		Not Available	PANEL, GRAPHICS

14	36700	Not Available	TIMER KNOB SKIRT
15	35333	Not Available	TIMER KNOB
16	36701	Not Available	KNOB, TEMP
17	34818	Not Available	END CAP(LEFT)
18	36335	40046601	Switch, Temperature Select
19	36045	40055101	Switch, Pressure
20	35038	Not Available	SWITCH/ WHITE

