


**Amana LW8363W2 (BOM: PLW8363W2 B) 10 - GRAPHIC PANEL, CTRL
MTG PLATE AND CTRLS**



Amana Residential Amana LW8363W2 (BOM: PLW8363W2 B) Washer Parts Parts Diagram 10 - GRAPHIC PANEL, CTRL MTG PLATE AND CTRLS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
2	34824		Not Available	TOP COVER
3	23962	W10116760		Screw
4	501086	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
6	35118	40039501		Switch, Speed
8	34904	489355		Screw, 8 X 1/2
9	34817		Not Available	END CAP(RIGHT)
10	34903		Not Available	PANEL, BACK HOOD (USE 37782)
12	34821		Not Available	CONTROL MOUNTING PLATE
14	36700		Not Available	TIMER KNOB SKIRT
15	35333		Not Available	TIMER KNOB
16	36701		Not Available	KNOB, TEMP
17	34818		Not Available	END CAP(LEFT)
18	36335	40046601		Switch, Temperature Select

