


Amana LW8413W2B (BOM: PLW8413W2 A) 13 - GRAPHIC PANEL, CTRL MTG PLATE AND CTRLS



Amana Residential Amana LW8413W2B (BOM: PLW8413W2 A) Washer Parts Parts Diagram 13 - GRAPHIC PANEL, CTRL MTG PLATE AND CTRLS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	34823		Not Available	COVER, TOP
"	34824W		Not Available	COVER, TOP (COMPUTOR)
2	23962	W10116760		Screw
3	Y34826		Not Available	DIFFUSER,LAMP-CLEAR
4	34904	489355		Screw, 8 X 1/2
5	31238			Timer, 2 Cycle
6	501086	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
7	34815		Not Available	PANEL, END R.H. (BLK)
"	34817		Not Available	END CAP(RIGHT)
8	34903		Not Available	PANEL, BACK HOOD (USE 37782)
9	34902P		Not Available	TOP
10	34821		Not Available	CONTROL MOUNTING PLATE
11	36628		Not Available	PANEL, GRAPHICS

"	37636W	Not Available	PANEL, GRAPHICS
"	36615	Not Available	PANEL, GRAPHICS
12	37773W	Not Available	SKIRT, TIMER KNOB
"	33817	Not Available	ASSY,TIMER SKIRT-BLACK
13	35333W		Knob, Timer
"	33897		Knob, Timer-Washer-Blac
14	34816		Panel, End
"	34818	Not Available	END CAP(LEFT)
15	35012		Switch, Pressure-Fixed

