


Amana LW8413W2B (BOM: PLW8413W2 A) 14 - GRAPHIC PANEL, CTRL MTG PLATE AND CTRLS



Amana Residential Amana LW8413W2B (BOM: PLW8413W2 A) Washer Parts Parts Diagram 14 - GRAPHIC PANEL, CTRL MTG PLATE AND CTRLS  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y34826		Not Available	DIFFUSER,LAMP-CLEAR
2	34824		Not Available	TOP COVER
3	23962	<a href="#">W10116760</a>		Screw
4	31239	<a href="#">31239P</a>		Timer 3 Cycle Package
"	<a href="#">36608</a>			Timer, 4 Cycle
5	34904	<a href="#">489355</a>		Screw, 8 X 1/2
6	501086	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
7	34817		Not Available	END CAP(RIGHT)
8	34903		Not Available	PANEL, BACK HOOD (USE 37782)
9	34902P		Not Available	TOP
10	36627		Not Available	GRAPHIC PANEL MODELS LW6123
"	36626		Not Available	GRAPHIC PANEL
"	36630		Not Available	GRAPHIC PANEL

11	34821	Not Available	CONTROL MOUNTING PLATE
12	36700	Not Available	TIMER KNOB SKIRT
13	35333	Not Available	TIMER KNOB
14	36701	Not Available	KNOB, TEMP
15	34818	Not Available	END CAP(LEFT)
16	<a href="#">35115</a>		Switch, TemPerature 3 P
"	36335	<a href="#">40046601</a>	Switch, Temperature Select
17	36045	<a href="#">40055101</a>	Switch, Pressure

