


**Amana LW8413W2B (BOM: PLW8413W2 A) 16 - GRAPHIC PANEL, CTRL  
MTG PLATE AND CTRLS**



Amana Residential Amana LW8413W2B (BOM: PLW8413W2 A) Washer Parts Parts Diagram 16 - GRAPHIC PANEL, CTRL MTG PLATE AND CTRLS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">34829</a>			Diffuser, Lamp-Clear
2	34824		Not Available	TOP COVER
3	23962	<a href="#">W10116760</a>		Screw
4	501086	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
5	<a href="#">34836</a>			Assembly, Fluorescent Light
6	35118	<a href="#">40039501</a>		Switch, Speed
7	<a href="#">36773</a>			Timer, 5 Cycle
8	34904	<a href="#">489355</a>		Screw, 8 X 1/2
9	34817		Not Available	END CAP(RIGHT)
10	34903		Not Available	PANEL, BACK HOOD (USE 37782)
11	34902P		Not Available	TOP
12	34821		Not Available	CONTROL MOUNTING PLATE
13	36624		Not Available	GRAPHIC PANEL MODELS

13	30024	Not Available	LW6163
"	36611	Not Available	PANEL, GRAPHICS
14	36700	Not Available	TIMER KNOB SKIRT
15	35333	Not Available	TIMER KNOB
16	36701	Not Available	KNOB, TEMP
17	34818	Not Available	END CAP(LEFT)
18	36335	<a href="#">40046601</a>	Switch, Temperature Select
19	36045	<a href="#">40055101</a>	Switch, Pressure
20	35038	Not Available	SWITCH/ WHITE

