


**Amana LW8463W2 (BOM: PLW8463W2 A) 08 - GRAPHIC PANEL, CTRL
MTG PLATE & CTRLS**



**GRAPHIC PANEL, CONTROL MOUNTING PLATE AND CONTROLS
(LW6183LM, LW6183WM, LW8413L2, LW8413W2 AND LW8463W2)**

Amana [Residential Amana LW8463W2 \(BOM: PLW8463W2 A\) Washer Parts](#) Parts Diagram 08 - GRAPHIC PANEL,
CTRL MTG PLATE & CTRLS
[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	501086	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
2	34818L		Not Available	PANEL,END-LH
"	34818W		Not Available	PANEL,END-LH
3	36335	40046601		Switch, Temperature Select
4	36045	40055101		Switch, Pressure
5	35038		Not Available	SWITCH/ WHITE
6	34829			Diffuser, Lamp-Clear
7	34824L			Cover, Top
"	34824W		Not Available	COVER, TOP (COMPUTOR)
8	23962	W10116760		Screw
9	34841		Not Available	STARTER,FLUORESCENT
"	34837		Not Available	BULB,FLUORESCENT
"	34836			Assembly, Fluorescent Light
10	36773			Timer, 5 Cycle

11	35118	40039501	Switch, Speed
12	34904	489355	Screw, 8 X 1/2
13	34817W		Not Available
	34817L		Not Available
14	Y00000000		Not Available
15	Y00000000		Not Available
16	34821		Not Available
17	36624W		Not Available
"	36611W		Not Available
"	36611L		Not Available
"	36616W		Not Available
"	36616L		Not Available
"	36624L		Not Available
18	36700W		Knob Skirt
"	36700L		Skirt, Timer
19	35333L		Knob, Timer
"	35333W		Knob, Timer
20	36701W		Knob
"	36701L		Knob

