


Amana LWA40AL2 (BOM: PLWA40AL2) 01 - AGITATOR, DRIVE BELL AND WASH TUB



W362PZ3A

Amana Residential Amana LWA40AL2 (BOM: PLWA40AL2) Washer Parts Parts Diagram 01 - AGITATOR, DRIVE BELL AND WASH TUB

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	27202	W10116787		Screw
2	28094			Gasket
3	39113	R9900144		Kit- Wash
4	37411	27001052		Balance Ring
5	39112	39371		Filter Lin
6	646P3	R9900552		Hub And Seal
7	29728	40008301		Insert, Spline
8	Y29220	40016301		Nut, Lock
9	36425	40016101		Seal, Bell Drive
10	39386	R9900144		Kit- Wash
11	36443P	R9900189		Kit, Drive Bell And Seal
12	36472			O-Ring
13	34288	40065102		Screw, Shoulder 1/4
14	36511	40008401		Plug, Bell
16	36507	40000501W		Agitator, Flex Vane

