


# Amana LWA40AL2 (BOM: PLWA40AL2) 11 - TRANSMISSION ASSEMBLY



Amana Residential Amana LWA40AL2 (BOM: PLWA40AL2) Washer Parts Diagram 11 - TRANSMISSION ASSEMBLY

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">Y36570</a>			Shaft, Output
2	<a href="#">35092</a>			Washer, 3628id X 1.00 X .056
3	<a href="#">27243P</a>			Oil, CW Transmission F-
4	<a href="#">26577</a>			Assembly, Gear And Stud
5	27030		Not Available	SCREW, 1/4-20 SPECIAL
6	<a href="#">21456</a>			Lockwasher, 1/4 Intshkp
7	26509	<a href="#">40041501</a>		Washer
8	<a href="#">37406</a>			Pinion, Drive
9	<a href="#">38268</a>			Shaft, Input
11	<a href="#">Y37471</a>			Assembly, Transmission Cover
12	38826P	<a href="#">12002178</a>		Transmison
13	<a href="#">37403</a>			Gear, Reduction
14	29260		Not Available	WASHER
16	<a href="#">Y31526</a>			Rack
17	<a href="#">26493</a>			Slide

18	<a href="#">27003</a>		Pinion, Agitator
19	33223	Not Available	ASSY, TRANSMISSION CASE
20	<a href="#">27197</a>		Ring, Retaining
NI	37577P	Not Available	SEALANT

