


Amana LWC18AW (BOM: PLWC18AW) 01 - AGITATOR, DRIVE BELL, WASHTUB AND HUB



Amana Residential Amana LWC18AW (BOM: PLWC18AW) Washer Parts Parts Diagram 01 - AGITATOR, DRIVE BELL, WASHTUB AND HUB
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	27202	W10116787		Screw
2	28094			Gasket
4	38378	39837		Assybalance Ring White
5	39112	39371		Filter Lin
6	646P3	R9900552		Hub And Seal
7	29728	40008301		Insert, Spline
8	Y29220	40016301		Nut, Lock
9	36425	40016101		Seal, Bell Drive
10	39240P			Wash Tub
11	36443P	R9900189		Kit, Drive Bell And Seal
12	36472			O-Ring
13	34288	40065102		Screw, Shoulder 1/4
14	36511	40008401		Plug, Bell
16	36507	40000501W		Agitator, Flex Vane
18	36542	40002101W		Assembly, Fabric Softner

