



Amana Residential Amana LWD250 (BOM: P7762128W W) Washer Parts Diagram 05 - Page 1
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	R0603110		Not Available	HOOD, CONTROL ASSY
2	R0605689		Not Available	END CAP L
"	R0605690		Not Available	END CAP R
6	R0603574		Not Available	GRAPHICS PANEL
7	R0603558		Not Available	KNOB, TIMER
8	R0603564		Not Available	SKIRT, TIMER ASSY
9	R0600095		Not Available	SCREW
12	R0604010	31238		Timer, 2 Cycle
13	R0600093	31260		Screw, No.8 X 3/8 Ind H
15	R0602525	31266		Switch, Pressure-Rotary
16	R0602532		Not Available	SWITCH TEMP.
17	R0601022		Not Available	NUT
18	R0600004	W10116760		Screw
19	R0610054		Not Available	ASSY,KNOB-ROTARY-BLK/O
20	R0601501		Not Available	CLIP
23	R0603103		Not Available	PANEL, REAR

