



Amana Residential Amana LWD352 (BOM: P7762114W W) Washer Parts Diagram 05 - Page 1  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	R0603193		Not Available	GRAPHIC PANEL
2	R0605719	<a href="#">31248</a>		Cap, End-RH-Chrome
"	R0605715		Not Available	END CAP, L.H CHROME
6	R0603194	<a href="#">33122</a>		Hood And Mounting Plate
7	R0603598		Not Available	KNOB, TIMER
8	R0603596		Not Available	ASSY, TIMER SKIRT & RIN
9	R0600095		Not Available	SCREW
12	R0604011	<a href="#">31239P</a>		Timer 3 Cycle Package
13	R0600093	<a href="#">31260</a>		Screw, No.8 X 3/8 Ind H
15	R0602525	<a href="#">31266</a>		Switch, Pressure-Rotary
16	R0602532		Not Available	SWITCH TEMP.
17	R0601022		Not Available	NUT
18	R0600004	<a href="#">W10116760</a>		Screw
19	R0601547		Not Available	KNOB, ASSY
20	R0601501		Not Available	CLIP
23	R0603103		Not Available	PANEL, REAR

