


# Amana LWD67AL (BOM: PLWD67AL) 05 - CONTROL PANEL



Amana [Residential Amana LWD67AL \(BOM: PLWD67AL\) Washer Parts](#) Parts Diagram 05 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	38231L	<a href="#">39905L</a>		Cover
2	23962	<a href="#">W10116760</a>		Screw
3	36335	<a href="#">40046601</a>		Switch, Temperature Select
4	36045	<a href="#">40055101</a>		Switch, Pressure
5	38367	<a href="#">40039501</a>		Switch, Speed
6	34904	<a href="#">489355</a>		Screw, 8 X 1/2
7	<a href="#">37922</a>			Timer, 115V/60Hz 6 Cycle
8	501086	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
9	504008L		Not Available	PANEL,END-RH ALMOND
10	<a href="#">37782</a>			Control Hood Back Panel
11	<a href="#">37992LP</a>			Top, Home W/Bleach
12	35887	<a href="#">40063901</a>		Clip, Hold Down
13	38171		Not Available	PANEL, CONTROL SUPPORT
14	Y00161	<a href="#">B5733302</a>		Clip, Ground
15	39823L		Not Available	PANEL,GRAPHIC(ALMOND)
16	<a href="#">36700L</a>			Skirt, Timer

17	<a href="#">35333L</a>		Knob, Timer
18	38424L	<a href="#">38424W</a>	Switch, Rocker
19	<a href="#">36701L</a>		Knob
20	504009L	Not Available	PANEL,END LH ALMOND

