


# Amana LWD67AW (BOM: PLWD67AW) 05 - CONTROL PANEL



Amana Residential Amana LWD67AW (BOM: PLWD67AW) Washer Parts Parts Diagram 05 - CONTROL PANEL  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	38231W	<a href="#">39905W</a>		Cover Top
2	23962	<a href="#">W10116760</a>		Screw
3	36335	<a href="#">40046601</a>		Switch, Temperature Select
4	36045	<a href="#">40055101</a>		Switch, Pressure
5	38367	<a href="#">40039501</a>		Switch, Speed
6	34904	<a href="#">489355</a>		Screw, 8 X 1/2
7	<a href="#">37922</a>			Timer, 115V/60Hz 6 Cycle
8	501086	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
9	504008W		Not Available	CAP-END RH
10	<a href="#">37782</a>			Control Hood Back Panel
11	<a href="#">37992WP</a>			Top, Home W/Bleach
12	35887	<a href="#">40063901</a>		Clip, Hold Down
13	38171		Not Available	PANEL, CONTROL SUPPORT
14	Y00161	<a href="#">B5733302</a>		Clip, Ground
15	39823W		Not Available	PNL, GRAPHIC
16	<a href="#">36700W</a>			Knob Skirt

17	<a href="#">35333W</a>		Knob, Timer
18	<a href="#">38424W</a>		Switch, Rocker
19	<a href="#">36701W</a>		Knob
20	504009W	<a href="#">40012702W</a>	Endcap

