


Amana LWD70AW (BOM: PLWD70AW) 04 - CONTROL PANEL



Amana Residential Amana LWD70AW (BOM: PLWD70AW) Washer Parts Parts Diagram 04 - CONTROL PANEL
 Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|-------------------------|---------------------------|---------------|---|
| 1 | 38231W | 39905W | | Cover Top |
| 2 | 23962 | W10116760 | | Screw |
| 3 | 35115 | | | Switch, TemPerature 3 P |
| 4 | 38842 | 40077201 | | Switch, Pressure |
| 5 | 34904 | 489355 | | Screw, 8 X 1/2 |
| 6 | 37919 | | Not Available | TIMER, 115V/60HZ 6 CYC |
| 7 | 501086 | 90767 | | Screw, 8A X 3/8 HeX Washer Head Tapping |
| 8 | 504008W | | Not Available | CAP-END RH |
| 9 | 37782 | | | Control Hood Back Panel |
| 10 | 37992WP | | | Top, Home W/Bleach |
| 11 | 35887 | 40063901 | | Clip, Hold Down |
| 12 | 38171 | | Not Available | PANEL, CONTROL SUPPORT |
| 13 | Y00161 | B5733302 | | Clip, Ground |
| 14 | 39121W | | Not Available | PANEL, GRAPHIC-AMANA |
| 15 | 36700W | | | Knob Skirt |
| 16 | 35333W | | | Knob, Timer |

17 [38424W](#)

Switch, Rocker

18 [36701W](#)

Knob

19 504009W

[40012702W](#)

Endcap

