



18

Amana Residential Amana LWD773W (BOM: P1122814W W) Washer Parts Parts Diagram 05 - Page 6  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	34155	<a href="#">40002101W</a>		Assembly, Fabric Softner
2	33174	<a href="#">40000501W</a>		Agitator, Flex Vane
3	32989	<a href="#">35035</a>		Guard, Clothes
4	<a href="#">33245</a>			Washtub, Stainless Steel
5	34288	<a href="#">40065102</a>		Screw, Shoulder 1/4
6	34289	<a href="#">36472</a>		O-Ring
7	34504	<a href="#">R9900189</a>		Kit, Drive Bell And Seal
8	34184	<a href="#">R9900189</a>		Kit, Drive Bell And Seal
9	32998	<a href="#">39371</a>		Filter Lin
10	27125	<a href="#">39122</a>		Gasket, Washtub
11	29728	<a href="#">40008301</a>		Insert, Spline
12	27202	<a href="#">W10116787</a>		Screw
13	<a href="#">28094</a>			Gasket
14	Y29220	<a href="#">40016301</a>		Nut, Lock
15	495P3	<a href="#">R9900552</a>		Hub And Seal