



Amana Residential Amana LWD973L (BOM: P1122817W L) Washer Parts Diagram 03 - Page 4  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	33445	<a href="#">27001095</a>		Switch, Lid
2	23962	<a href="#">W10116760</a>		Screw
3	<a href="#">33442</a>			Lever, Unbalanced Load
4	<a href="#">33443</a>			Spring
5	33440	<a href="#">36497P</a>		Kit, Switch Holder
6	33433		Not Available	CLIP,HOLDER-SWITCH
7	<a href="#">33441</a>			Arm, Actuator
8	<a href="#">29210</a>			Hose Clamp
9	<a href="#">33186</a>			Hose, Water Inlet
10	29176	<a href="#">285655</a>		Clamp, Hose
11	<a href="#">34280</a>			Assembly, Backflow Prevento
12	23962	<a href="#">W10116760</a>		Screw
13	27152		Not Available	CLAMP HOSE
14	<a href="#">27183</a>			Hose, Mixing Valve
15	27152		Not Available	CLAMP HOSE
16	32837	<a href="#">39407</a>		Bracket, Valve

17	56392		Not Available	SCREW,8-18 X 3/8 TAPPI
18	<a href="#">33930</a>			Valve, Mixing
19	Y24159	<a href="#">33930</a>		Valve, Mixing
21	24134		Not Available	DIAPHRAGM
22	24132		Not Available	ARMATURE
23	24131		Not Available	SPRING
24	<a href="#">24130</a>			Guide, Armature
25	24129		Not Available	SLEEVE,SHORT
26	33930A	<a href="#">33930</a>		Valve, Mixing
27	24128		Not Available	SLEEVE,LONG
28	25817C		Not Available	SCREW
29	24122	<a href="#">22002960</a>		Strainer, Washer Inlet
30	Y21899	<a href="#">40038101</a>		Nut, Leg
31	Y34319	<a href="#">22003428</a>		Leg, Adjustable
32	34318	<a href="#">40016001</a>		Foot, Rubber

