


Amana LWS17AW (BOM: PLWS17AW) 07 - GRAPHIC PANEL, CTRL MTG PLATE AND CTRLS



Amana Residential Amana LWS17AW (BOM: PLWS17AW) Washer Parts Parts Diagram 07 - GRAPHIC PANEL, CTRL MTG PLATE AND CTRLS

Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	Y504009	40012702W		Endcap
2	501086	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
3	38231		Not Available	TOP COVER
4	23962	W10116760		Screw
5	35115			Switch, TemPerature 3 P
6	38842	40077201		Switch, Pressure
7	37929			Timer, 115V/60Hz 3 CYC
8	34904	489355		Screw, 8 X 1/2
9	Y504008		Not Available	END CAP RIGHT (ADD LETTER L-L, W-W TO PART N
10	37782			Control Hood Back Panel
11	37992P		Not Available	CABINET TOP
12	35887	40063901		Clip, Hold Down
13	38887		Not Available	GRAPHIC PANEL MODELS

13	38887	Not Available	LWS01Ax
14	38171	Not Available	PANEL, CONTROL SUPPORT
15	Y00161	B5733302	Clip, Ground
16	38841W	Not Available	SKIRT, TIMER KNOB
17	33898	Not Available	TIMER KNOB WHITE
18	33688	36701W	Knob

