


# Amana NA4320 14 - OUTER TUB, COVER & PRESSURE HOSE



## OUTER TUB, COVER AND PRESSURE HOSE

Amana [Residential Amana NA4320 Washer Parts](#) Parts Diagram 14 - OUTER TUB, COVER & PRESSURE HOSE  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">03815</a>			Lockwasher, No.10 Ext Shk
2	29901		Not Available	PLUG,SNAP-IN-OUTER TUB
3	Y00000000		Not Available	SEE NOTE PRESSURE SWITCH
4	29213	<a href="#">39125</a>		Tubing 31
5	Y22294	<a href="#">596669</a>		Clamp, Manifold
6	30243	<a href="#">40008501</a>		Assembly, Pressure Bulb
7	29175	<a href="#">40037801</a>		Grommet
8	Y27195		Not Available	STICKER
9	Y00000000		Not Available	SEE NOTE SUPPORT LEG
10	<a href="#">27927</a>			Plate, Leg .032
11	<a href="#">27926</a>			Plate, Leg .063
12	27205	<a href="#">40128701</a>		Screw, 5/16-18 X .50
13	<a href="#">27239</a>			Spring, Leg
14	30508		Not Available	TUB,OUTER
"	30509		Not Available	OUTER TUB
15	Y27017		Not Available	CLIP,SPRING

16	<a href="#">27184</a>		Gasket, Tub Cover
17	31141	<a href="#">31153</a>	Cover Outer Tub
18	23425	Not Available	WASHER,7/32IDX7/16ODX.
19	<a href="#">27247</a>		Trigger, Out-Of-Bal Swi
20	27523	Not Available	SCREW

