


Amana NA7321 14 - OUTER TUB, COVER & PRESSURE HOSE



OUTER TUB, COVER AND PRESSURE HOSE

Amana [Residential Amana NA7321 Washer Parts](#) Parts Diagram 14 - OUTER TUB, COVER & PRESSURE HOSE
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	03815			Lockwasher, No.10 Ext Shk
2	29901		Not Available	PLUG,SNAP-IN-OUTER TUB
3	Y00000000		Not Available	SEE NOTE PRESSURE SWITCH
4	29213	39125		Tubing 31
5	Y22294	596669		Clamp, Manifold
6	30243	40008501		Assembly, Pressure Bulb
7	29175	40037801		Grommet
8	Y27195		Not Available	STICKER
9	Y00000000		Not Available	SEE NOTE SUPPORT LEG
10	27927			Plate, Leg .032
11	27926			Plate, Leg .063
12	27205	40128701		Screw, 5/16-18 X .50
13	27239			Spring, Leg
14	30508		Not Available	TUB,OUTER
"	30509		Not Available	OUTER TUB
15	Y27017		Not Available	CLIP,SPRING

16	27184		Gasket, Tub Cover
17	31141	31153	Cover Outer Tub
18	23425	Not Available	WASHER,7/32IDX7/16ODX.
19	27247		Trigger, Out-Of-Bal Swi
20	27523	Not Available	SCREW

