


# Amana SLG120RAW (BOM: PSLG120RAW) 03 - Door and Front, Access, and Top Panels



Amana Residential Amana SLG120RAW (BOM: PSLG120RAW) Washer Parts Parts Diagram 03 - Door and Front, Access, and Top Panels  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">503688</a>			Screw, 10B-16 X .34 I
2	501086	<a href="#">90767</a>		Screw, 8A X 3/8 HeX Washer Head Tapping
3	500343		Not Available	PANEL,BACK(HOME HOOD)
4	<a href="#">Y503876</a>			Clip, Hold Down
5	40070301W	<a href="#">37001027</a>		Panel, Top
6	32671	<a href="#">Y014874</a>		Screw, Idler Arm And Sleeve
7	<a href="#">505187</a>			Locator, Panel
8	56080	<a href="#">22001650</a>		Fastener, Spring
9	503661	<a href="#">27001200</a>		Screw
10	500084	<a href="#">40130801</a>		Bracket, Top Mount
11	504005	<a href="#">511056</a>		Seal Front Panel
12	Y504570	<a href="#">W10169313</a>		Switch-Dor
13	<a href="#">503126</a>			Plug, Hinge Hole
14	503639W	<a href="#">503656WP</a>		Panel, Front

15	40045302WP	<a href="#">40045301WP</a>	Panel, Access
16	54660	<a href="#">LA-1003</a>	Door Catch Kit
17	503643W	<a href="#">37001028</a>	Seal And Liner, Assembly
18	500039	<a href="#">510181</a>	Strike Doormetal
19	500223	<a href="#">40116201</a>	Bracket, Door Strike
20	<a href="#">500226</a>		Screw, 8b-16 x 5/8 Tap
21	<a href="#">505328</a>		Wedge, Door Handle
22	503646W	<a href="#">R9800012</a>	Pull, Door
23	503642WP	<a href="#">12002136</a>	Door Handle
24	<a href="#">Y503676</a>		Hinge, Door And Top

